

Key:		I = Inspect / adjust if required						L = Lubricate		R = Replace		T = Tighten					
No.		P1	P2	P3	No.		P1	P2	P3	Additional service items							
drive vehicle into workshop						LHF	RHF	LHR	RHR	Spare							
1	Dash warning lamps, gauges and lights on buzzer	I		I	31	Tread depth					Brake fluid - 2yr/27000 miles						
2	Steering wheel free play	I		I		Pressure											
3	Seat belts and operation	I		I	32	Wheel nut torques											
outside the vehicle					drive vehicle off ramp						Fuel Filter	18,000 miles - diesel					
4	Exterior bodywork visual inspection	I		I	33	All drive belts	I		I		36,000 miles - petrol						
5	Wipers/wiper blade function/condition	I		I	34	Windshield washer top-up fluid level	I		I		n/a N16 QG engines						
6	Doors/door locks	L		L	35	Battery fluid level	I		I								
7	Hood latches	L		L	36	Check air conditioning hoses and connectors - if fitted		I		I	Antifreeze - 3yr/36000 miles						
8	Door hinges, latches, links & rollers	L		L	37	Check cooling system for condition and leaks	I		I								
9	All exterior lamps/indicators functioning	I		I	38	Coolant/anti-freeze strength - see additional items		I		I							
10	Headlamp aiming	I		I	39*	Air cleaner filter (viscous paper and dry paper type)		R		R	Cambelt - 5yr/54000 miles						
drive vehicle on to ramp					40	PCV valve and system		I		I							
11*	Engine oil	R		R	41*	PCV filter (where applicable)		R		R							
12*	Engine oil filter	R		R	42	Valve clearance (non HLA models)		I		I	platinum tipped spark plugs						
13	Manual transmission oil - levels and leaks				43	Fuel and vapour lines		I		I	5yr/54000 miles						
	Y61, R20 (replace at 54k miles)	I		I	44	Spark plugs - conventional spark plugs		R		R							
	Others	I		I		platinum spark plugs - see additional items					Inspect airbag system						
14*	Transfer and standard differential gear oil - levels and leaks				45	Ignition leads		I		I	10yrs/ every 2 yrs						
	Y61, R20 (replace at 36k miles)	I		I	46	EGR valve & ASCD vacuum hoses	I		I		Notes						
	Others				47	Oxygen sensor (exhaust gas sensor)/lambda value		I		I							
15*	LSD gear oil (except viscous coupling type)	I		I	48	Idle speed (including base idle) & ignition timing	I		I								
16*	A/T & NCVT fluid - level, leakage	I		I	49	Brake booster vacuum hoses, connection, chk valve		I		I							
17*	NCVT fluid change (only at P3 for Primera CVT)		R		50	Clutch system - fluid level & leaks, pedal free play	I		I								
18	NCVT magnetic clutch carbon brush		I		51	Manual steering gear oil (where applicable)	I		I								
19*	Steering gear and linkage (4x4)	I		I	52	Power steering - levels and leaks	I		I								
	axle suspension, propeller (others)		I		53*	Cabin air filter		R		R							
	shaft and exhaust system				54	Check cruise control vacuum hoses and connections	I		I								
20*	Greasing points of steering gear linkage (4x4)	L		L	55	Road test	I		I								
	prop shaft and suspension				56	Wheel alignment, if necessary, balance wheels	I		I								
21*	Drive shafts and steering damper	I		I	57	Check exhaust emissions		I		I	Mileage						
22*	Front wheel bearing grease (4x4)	I		R	Diesel: If engine power decreases, black exhaust smoke is emitted or engine noise increases, check injection nozzles and if necessary, replace injection nozzle assembly							Date					
23	Front axle joint grease in knuckle flange (Y61)		L														
24*	Free running hub grease (4x4)	I		I													
25	Body mounting bolts and nuts (check for security)	T		T													
26	Body corrosion	I		I	*Change frequency as required under severe weather conditions								Mileage	Date			
27*	Front brake pads, discs & other components	I		I													
28*	Rear brake pads, linings, drums and other components	I		I													
29	Foot brake, parking brake: operation/free play/stroke	I		I													
30*	Brake fluid - check for level and leaks - see additional items	I		I													
P1 - 9000, 27000, 45000, 63000, 81000miles															P2 - 18000, 54000, 90000 miles		P3 - 36000, 72000 miles